

# ADJUST-A-GRATE


A grate solution that covers the hole problem®

## SELECTING THE RIGHT MODEL



Adjust-A-Grates fit inside the opening of the window well, therefore only use inside dimensions when measuring.

Measure the length along the house and the projection out from the house at the widest points and then select the correct model for your size and shape of well.



303.278.6262  
1.888.877.4728



www.grate.com

# CUSTOM FIT WITHOUT THE CUSTOM PRICE

## ADJUSTABLE




Adjust-A-Grate window well covers are designed to offer you a custom fit without the custom price. Each grate is designed to adjust side to side so that it perfectly conforms to the contour of your well.

The grate does not adjust front to back, the range given for the projection out from the house for each model is simply the acceptable range for that model of grate.

If your measurement is near the lower end of the range you will have a smaller gap at the back of the grate, against the house. If your measurement is near the higher end of the range you will have a larger gap at the back of the grate.

See the full installation video at [grate.com/installation](https://grate.com/installation)




Each loop moves independently

## COMMON WELL SHAPES



### RECTANGULAR



- ▶ Typically a concrete or wood well, rectangular in shape that does not narrow or only slightly narrows as it comes away from the house.
- ▶ May be a metal well that is mostly rectangular but has rounded front corners.

USE **RECTANGULAR** SIZE CHART, PG 3.

### STANDARD




- ▶ Typically a metal well that tapers as it comes away from the house with rounded front corners.
- ▶ May have concrete poured around the lip of the well such as a patio or sidewalk.
- ▶ Smaller wells are nearly a perfect semi-circle.

USE **STANDARD** GRATE SIZE CHART, PG 2.

Most  
Common

### PRECAST



- ▶ Precast concrete wells with 5 or 7 sides not including the house.
- ▶ Ensure you are measuring the inside dimensions only, do not include the wall of the well in your measurement.
- ▶ Some sizes of precast grate models are not available to ship due to size.

USE **PRECAST** SIZE CHART, PG 3.

# STANDARD GRATE SIZE CHART



## SELECTING THE RIGHT MODEL



Adjust-A-Grates fit inside the opening of the window well, therefore only use inside dimensions when measuring.

Measure the **length along the house** (listed on the top of chart) and the **projection out from the house** (listed on the left side of chart) at the widest points and then select the correct model for your size and shape of well using the chart to the right.

303.278.6262  
1.888.877.4728

[www.grate.com](http://www.grate.com)

**Length Along The House At Widest Point (inches)**

	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	+
<b>15</b>	<b>Model S4*</b>																																					
<b>16</b>																																						
<b>17</b>	<b>Model L4</b>																																					
<b>18</b>																																						
<b>19</b>	<b>Model L5</b>																																					
<b>20</b>																																						
<b>21</b>	<b>Model L6</b>																																				<b>Model XL6</b>	
<b>22</b>																																						
<b>23</b>	<b>Model L7</b>																																				<b>Model XL7</b>	
<b>24</b>																																						
<b>25</b>	<b>Model L8</b>																																				<b>Model XL8</b>	
<b>26</b>																																						
<b>27</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>28</b>																																						
<b>29</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>30</b>																																						
<b>31</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>32</b>																																						
<b>33</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>34</b>																																						
<b>35</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>36</b>																																						
<b>37</b>	<b>Model L9</b>																																				<b>Model XL9</b>	
<b>+</b>																																						

\* Semi Circle Wells Only


If the size of your well does not match any of the models shown, then contact Adjust-A-Grate Inc. for alternatives.

**Projection Out From House in Center of Well (inches)**


## STANDARD 6-LOOP GRATE MODELS



### MODEL L6



### MODEL XL6



For openings that are 60 inches in length along the house, both the L6 or XL6 Models will work.

However, please note that the L6 will be at its maximum width and therefore will flex more versus the XL6 that will be much more rigid as 60 inches is its minimum width. For this reason we recommend the XL6 for higher traffic areas.

Adding a Security Kit?  
Use Model SK6 with L6 & XL6 Grates

The above models will not fit rectangular wells, see page 3.

# RECTANGLE GRATE SIZE CHART



## SELECTING THE RIGHT MODEL



Adjust-A-Grates fit inside the opening of the window well, therefore only use inside dimensions when measuring.

Measure the **length along the house** (listed on the top of chart) and the **projection out from the house** (listed on the left side of chart) at the widest points and then select the correct model for your size and shape of well using the chart to the right.

303.278.6262  
1.888.877.4728

www.grate.com

**Length Along The House At Widest Point (inches)**

	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	+			
14 ½																																					
15																																					
16																																					
17																																					
17 ½																																					
18																																					
19																																					
20																																					
21																																					
22																																					
23																																					
24																																					
25																																					
26																																					
27																																					
28																																					
29																																					
30																																					
31																																					
32																																					
33																																					
34																																					
35																																					
36																																					
37																																					
+																																					


**Projection Out From House in Center of Well (inches)**

If the size of your well does not match any of the models shown, then contact Adjust-A-Grate Inc. for alternatives.

## PRECAST MODELS




### MODEL L6




The standard Model L6 will work for a precast concrete well.

### MODEL PC8



### MODEL PC10



\* Available in Colorado, Not Eligible For Shipping. Contact Adjust-A-Grate for Additional Information